FITTING GUIDE

WHITE SILICONE CASE EDGE 1040 / 1030

White soft silicone case moulded for the body shared by the Edge 1040 and 1030: buttons, charging port and quarter-turn mount stay free. It slips on without tools.

GARMIN EDGE 1040 / 1030 · SOFT HIGH-RESISTANCE SILICONE · WHITE



Before fitting

- Computer **off its mount**, switched off, body clean and dry: a grain of sand trapped under the case scratches the computer every time you handle it.
- If you are also fitting a tempered glass: **glass first**, case second, as the case overlaps its edges.
- No tools: the case slips on by hand.

Fitting

1. **Orient the case:** button cut-outs on the button side, charging port opening at the bottom, round opening on the back for the quarter-turn mount.
2. **Hook one corner,** then roll the case over the body with a slight stretch until it reaches the opposite corner. It settles on its own.
3. **Press around the rim** so the edge sits fully down all around the screen, without overlapping it.
4. **Check the cut-outs:** every button moves freely, the charging port is reachable, the mount on the back is clear.
5. **Clip the computer** onto its mount with the case on: the quarter-turn must lock with a firm click.

Care

- Take the case off, wash it in warm soapy water, rinse and dry it before refitting. No solvents.
- After a wet ride, take it off once home: water trapped between case and body needs to dry.
- White silicone may tint slightly over time with sweat; this does not affect the protection.

On video

Independent tutorial, scan to watch.

Garmin 830 silicone case and screen protector
Brickfuze · English

Specifications

Compatibility	**Edge 1040 / 1030**	Material	**Soft silicone**
Colour	**White**	Protects from	**Impacts, scratches, splashes**
Kept free	**Buttons, charging, mount**	Contents	**1 case**

IF SOMETHING GOES WRONG

- **Stiff button, or one that stays pressed:** the cut-out is not in line; lift that side of the case and recentre it.
- **Computer will not lock** on the mount: the case is riding up around the rear opening; push it fully down, then try again.
- **Edge overlapping the screen:** the case is not fully down on one corner; press all four corners.

WHAT IT DOES NOT DO

- It does not make the computer waterproof, does not protect the screen (that is the job of a tempered glass) and is no substitute for a mount in good condition.

Need help?

velkyne.com/contact
Our team answers your questions about fitting and compatibility.