VELKYNE

FITTING GUIDE

# SILICONE CASE EDGE 850 / 550

Soft silicone case, 15 g, moulded for the body shared by the Edge 850 and 550, with raised edges around the screen. Buttons, charging port, touchscreen and quarter-turn mount stay free.

**GARMIN EDGE 850 / 550** · SOFT SILICONE, 15 G · RAISED EDGES, BLACK



## Before fitting

- Computer **off its mount**, switched off, body clean and dry: a grain of sand trapped under the case scratches the computer every time you handle it.
- If you are also fitting a tempered glass: **glass first**, case second, as the case overlaps its edges.
- No tools: the case slips on by hand.

## Fitting

1. **Orient the case:** button cut-outs on the button side, charging port opening at the bottom, round opening on the back for the quarter-turn mount.
2. **Hook one corner,** then roll the case over the body with a slight stretch until it reaches the opposite corner. It settles on its own.
3. **Press around the rim** so the edge sits fully down all around the screen, without overlapping it.
4. **Check the cut-outs:** every button moves freely, the charging port is reachable, the mount on the back is clear.
5. **Clip the computer** onto its mount with the case on: the quarter-turn must lock with a firm click.

## Care

- Take the case off, wash it in warm soapy water, rinse and dry it before refitting. No solvents.
- After a wet ride, take it off once home: water trapped between case and body needs to dry.

## On video

Independent tutorial, scan to watch.

**Garmin 830 silicone case and screen protector**
Brickfuze · English

## Specifications

| | | | |
|---|---|---|---|
| Compatibility | **Edge 850 / 550** | Material | **Soft silicone** |
| Dimensions | **9.46 × 5.59 × 2 cm** | Weight | **15 g** |
| Protects from | **Impacts, drops, scratches** | Kept free | **Buttons, charging, mount** |

### IF SOMETHING GOES WRONG

- **Stiff button, or one that stays pressed**: the cut-out is not in line; lift that side of the case and recentre it.
- **Computer will not lock** on the mount: the case is riding up around the rear opening; push it fully down, then try again.
- **Edge overlapping the screen**: the case is not fully down on one corner; press all four corners.

### WHAT IT DOES NOT DO

- It does not make the computer waterproof and does not cover the display: its raised edges keep it off surfaces, a tempered glass protects it from scratches. It is no substitute for a mount in good condition.

## Need help?

**velkyne.com/contact**
Our team answers your questions about fitting and compatibility.

© 2026 Velkyne. All rights reserved.