FITTING GUIDE

HYDROGEL FILM GARMIN EDGE 1050

Flexible 0.5 mm hydrogel film, oleophobic, touch preserved, cut for the Edge 1050. A soft film is rolled on from one edge to the other: follow the order.

GARMIN EDGE 1050 · HYDROGEL FILM 0.5 MM · OLEOPHOBIC



Before fitting

- A room with **no dust in the air** and no draught; clean hands, computer switched off, screen dry.
- Something to clean with: a damp wipe or alcohol, a microfibre cloth, a dust-removal sticker or adhesive tape, and a **soft card** for smoothing.
- The film is soft and tacky: always hold it by the edges, and never pull on it to reposition, it would stretch out of shape. It is cut for the Edge 1050 only, not for the 1040 or 1030.

Fitting, step by step

1. **Clean the screen** with alcohol or the damp wipe, dry it with the microfibre, then dab it with the tape. Check against the light: no smear, no grain.
2. **Dry-fit the film** with its backing on: it covers the screen right up to its rounded edges and clears the buttons. Note this position.
3. **Peel the backing** off the adhesive side by one third only, holding the film by its edges. Do not touch the sticky side.
4. **Anchor the first edge** on the mark and press it down with the card. Remove the rest of the backing while rolling the film onto the screen, the card following just behind.
5. **Smooth from the centre to the edges** with the card, then press all around the outline. Leave it 24 h without touching it: small bubbles clear on their own.

Specifications

Compatibility	**Edge 1050**	Thickness	**0.5 mm**
Material	**Hydrogel**	Surface	**Oleophobic**
Touch	**Preserved**	Protects from	**Scratches, knocks**

IF SOMETHING GOES WRONG

- **Trapped dust** (dot with a halo): lift the nearest edge, pick the particle off with tape, lay it back down while smoothing.
- **Edge lifting**: press firmly with the card; if it comes back, there is a greasy mark underneath: lift, clean, refit.
- **Visible scratch**: the film took it instead of the screen; replace it once it gets in the way of reading.

DON'T

- No fitting on a cracked screen, nor under a case already in place: the case goes on after the film. No hard object or fingernail for smoothing: the soft card only.

On video

Independent tutorial, scan to watch.

How to install a hydrogel screen protector, step by step
Madam C · English

Need help?

velkyne.com/contact
Our team answers your questions about fitting and compatibility.