VELKYNE

FITTING GUIDE

STICK-ON PHONE ADAPTER FOR GARMIN MOUNTS

7 g ABS puck that sticks to the back of your phone case and clips with a quarter turn onto any Garmin-type computer mount. Fitting only happens once: clean, stick, wait.



GARMIN-TYPE BIKE MOUNTS · ABS, 5 × 3.5 × 0.6 CM, 7 G · HIGH-STRENGTH ADHESIVE, NOT FOR SILICONE CASES

Before fitting

- A **hard** case, plastic or polycarbonate, clean: the adhesive does not hold on soft silicone or on a textured finish. Avoid a bare phone, the adhesive is made to stay.
- An alcohol wipe, a dry cloth, and the patience to wait before riding.

Fitting, step by step

1. **Degrease the back of the case** with alcohol, then let it dry completely. No fingerprints on the bonding area.
2. **Check the position** without removing the film: puck centred on the phone, away from the lenses, tabs running lengthwise so the screen sits straight once clipped on. Do not reposition once stuck.
3. **Peel the film** off the adhesive without touching the sticky side, then lay the puck down and press firmly for thirty seconds over its whole surface.
4. **Wait 24 hours** before riding: the adhesive reaches full strength with time, not with force.
5. **Clip the phone on** the mount, tabs in the notches, then a quarter turn until it clicks. To remove it, turn the other way: never pull upward.

DON'T

- Do not ride without a safety lanyard: a heavy phone on trails or cobbles remains a risk, whatever the mount. Do not handle the phone while riding.

DAY TO DAY

Before every ride, take a look: the puck must sit flat, with no lifting edge. After a wet ride, wipe the back of the case.

Specifications

Compatibility	Garmin-type mounts	Material	ABS, black
Size	5 × 3.5 × 0.6 cm	Weight	7 g
Attachment	High-strength adhesive	Other uses	GPS, camera, walkie-talkie

IF SOMETHING GOES WRONG

- **An edge lifts**: greasy, textured or soft surface. Peel off, clean, fit a new puck on a hard case; a lifted adhesive cannot be re-stuck.
- **The phone will not lock**: line the tabs up with the notches and turn until it clicks.
- **The screen sits crooked**: puck stuck at an angle; only a new puck, fitted straight, will fix it.

Need help?

velkyne.com/contact

Our team answers your questions about fitting and compatibility.

© 2026 Velkyne. All rights reserved.