FITTING GUIDE

RED AND WHITE SKIN EDGE 1050

Set of pre-cut PVC stickers for the body of the Garmin Edge 1050, in a red and white pattern. Plan the fitting on the supplied template, then apply piece by piece, from the centre outwards.

GARMIN EDGE 1050 · WATERPROOF, SCRATCH-RESISTANT PVC · RED AND WHITE PATTERN



Before fitting

- Computer **off its mount**, switched off; body cleaned, degreased (alcohol wipe) and **completely dry**: a single fingerprint is enough to stop the adhesive bonding.
- A room with no dust in the air, clean hands, good light.
- The **supplied template** in front of you: it shows where each piece goes. Locate them all before peeling the first one.

Fitting, piece by piece

1. **Identify the piece** on the template and lay it on its surface without peeling it, to spot its outline and cut-outs.
2. **Peel it from one edge,** holding it by the side, without touching the adhesive face.
3. **Align before pressing:** lay the longest edge on its reference first (body edge, button cut-out), check, then let the rest settle.
4. **Smooth from the centre outwards** with your thumb or a soft card to push the air out. On a corner that will not follow, a breath of warm air (hair dryer at a distance) softens the PVC: hold it down until it cools.
5. **Move on to the next piece** in template order, then check every outline: no edge may lift.
6. **Leave it overnight** before riding. To remove a piece, warm it slightly and peel it slowly from a corner.

On video

Independent tutorial, scan to watch.

How to place stickers with no bubbles or wrinkles
my mechanics insights · English

Specifications

Compatibility	**Edge 1050**	Material	**PVC**
Finish	**Red and white**	Protects from	**Scratches, moisture**
Fitting	**Adhesive, pre-cut**	Contents	**Kit + fitting template**

IF SOMETHING GOES WRONG

- **Bubble**: push it to the nearest edge. If it will not move, there is dust underneath: lift the piece, pick the dust off with adhesive tape, lay it back down.
- **Misaligned piece**: peel it off gently right away and lay it again; the adhesive tolerates repositioning as long as it has not set.
- **Lifting corner**: warm air, then firm pressure until it cools.

DON'T

- Nothing on the screen, the buttons, the charging port or the sensors: the cut-outs leave them free, and the screen is protected separately (Velkyne 1050 hydrogel film). Never a heat gun, never a fitting on a cold or damp body.

Need help?

velkyne.com/contact
Our team answers your questions about fitting and compatibility.

© 2026 Velkyne. All rights reserved.