FITTING GUIDE

BOTTOM BRACKET AND CRANK-END STICKERS

Two universal stickers with a 3D abrasion-resistant relief, for the bottom bracket shell and the crank ends: the areas the chain, grit and shoes damage first.



ALL FRAMES: ROAD, GRAVEL, MTB, HYBRID, URBAN · 3D ABRASION-RESISTANT RELIEF · SET OF 2

Before fitting

- **Find the areas**: the underside of the bottom bracket shell, hit by grit and the chain, and the crank ends, scratched by shoes.
- **A warm room**, rubbing alcohol, a microfibre cloth. Clean hands, sticker held by its edges.

Fitting, step by step

1. **Degrease the area with alcohol** and let it dry. No wax or polish: the adhesive would not hold.
2. **Dry-fit each sticker,** backing still on, to find the position that covers the rubbed area without straddling a sharp edge.
3. **Peel the backing** back a few centimetres, lay one edge down and press, then remove the rest as you go.
4. **Press from the centre outwards** with your thumb or the cloth, following the curve without trapping air.
5. **Let it cure overnight** before riding or washing the bike.

Removal without marks

- Warm gently with a hairdryer to soften the adhesive, then peel slowly, pulling back at 180°.
- On thin or already weakened paint, some paint may lift: test on a hidden spot first.

On video

Independent tutorial, scan to watch.

How to apply clear protective vinyl wrap on your bike
The Duke of MTB · English

Specifications

Compatibility	**Universal, all frames**	Areas	**Bottom bracket shell, crank ends**
Texture	**3D abrasion-resistant relief**	Protects from	**Scratches, light knocks**
Removal	**Residue-free, with heat**	Contents	**2 stickers**

IF SOMETHING GOES WRONG

- **A bubble**: push it to the edge; if it resists, prick it with a needle and press.
- **An edge lifts**: area not degreased, or edge too sharp. Press again; if it comes back, peel off and refit.
- **It is on crooked**: lift it straight away, while the glue is fresh, and go back to step 2.

DON'T

- No fitting in the cold, on chipped paint or a damp frame. Never rip it off dry: the paint comes with it. For the bottom bracket shell alone, the Velkyne universal sticker is enough.

Need help?

velkyne.com/contact
Our team answers your questions about fitting and compatibility.

© 2026 Velkyne. All rights reserved.