FITTING GUIDE

SILICONE RINGS FOR BAR TAPE

A pair of soft silicone rings that lock the end of the bar tape in place of the finishing tape, and shield the bar ends from water and dust. Tool-free fitting.

ROAD, GRAVEL, MTB, CITY · SOFT SILICONE, BLACK · 2 × 2.7 CM, APPROX. 3.5 G



Before fitting

- The ideal moment: when you change the tape. On tape already in place, the ring rolls up on itself to pass the bar end.
- Remove the bar end plug. No tools, no adhesive. The rings rinse with water and go back on the next tape.

Fitting, step by step

1. **Slide the ring** onto the bare bar end before wrapping, and push it up towards the lever. On tape already in place: roll the ring up on itself, pass it over, unroll it.
2. **Wrap the tape** from the bar end towards the stem, letting the first turn overhang the bar end.
3. **Bring the ring back** over the end of the tape, at the bar end: it covers the last turn and its cut edge, lying flat.
4. **Refit the plug,** tucking in the overhanging tape: the plug locks the first turn, the ring locks the last.
5. **Check** that the ring presses the tape flat with no fold and that the plug is seated. Same on the other side.

DON'T

- The ring does not replace the bar end plug: always ride with both plugs in place. Do not stretch a split or hardened ring.

Specifications

Contents	**1 pair**	Material	**Soft silicone**
Size	**2 × 2.7 cm**	Weight	**approx. 3.5 g each**
Compatibility	**Road, gravel, MTB, city**		

IF SOMETHING GOES WRONG

- **The ring slips or turns**: it must sit on the tape, not on the bare bar.
- **The tape still comes loose**: the cut edge is not under the ring, or the first turn is not tucked under the plug; go back to steps 2 to 4.

On video

Independent tutorial on wrapping bar tape, scan to watch.

Every Cyclist Needs to Know How To Wrap Handlebar Tape

David Arthur, Just Ride Bikes · English

Need help?

velkyne.com/contact

Our team answers your questions about fitting and compatibility.