FITTING GUIDE

SILICONE CASE EDGE 530 / 830

Soft silicone case moulded for the body shared by the Edge 530 and 830: buttons, charging port and quarter-turn mount stay free. It slips on without tools, in a minute.

GARMIN EDGE 530 / 830 · SOFT SHOCK-ABSORBING SILICONE · BUTTONS AND PORT FREE



Before fitting

- Computer **off its mount**, switched off, body clean and dry: a grain of sand trapped under the case scratches the computer every time you handle it.
- If you are also fitting a tempered glass: **glass first**, case second, as the case overlaps its edges.
- No tools: the case slips on by hand.

Fitting

1. **Orient the case:** button cut-outs on the button side, charging port opening at the bottom, round opening on the back for the quarter-turn mount.
2. **Hook one corner,** then roll the case over the body with a slight stretch until it reaches the opposite corner. It settles on its own.
3. **Press around the rim** so the edge sits fully down all around the screen, without overlapping it.
4. **Check the cut-outs:** every button moves freely, the charging port is reachable, the mount on the back is clear.
5. **Clip the computer** onto its mount with the case on: the quarter-turn must lock with a firm click.

Care

- Take the case off, wash it in warm soapy water, rinse and dry it before refitting. No solvents.
- After a wet ride, take it off once home: water trapped between case and body needs to dry.

On video

Independent tutorial, scan to watch.

Garmin 830 silicone case and screen protector
Brickfuze · English

Specifications

Compatibility	**Edge 530 / 830**	Material	**Soft silicone**
Protects from	**Impacts, scratches, dust**	Kept free	**Buttons, charging, mount**
Fitting	**No tools**	Contents	**1 case**

IF SOMETHING GOES WRONG

- **Stiff button, or one that stays pressed**: the cut-out is not in line; lift that side of the case and recentre it.
- **Computer will not lock** on the mount: the case is riding up around the rear opening; push it fully down, then try again.
- **Edge overlapping the screen**: the case is not fully down on one corner; press all four corners.

WHAT IT DOES NOT DO

- It does not make the computer waterproof, does not protect the screen (that is the job of a tempered glass) and is no substitute for a mount in good condition.

Need help?

velkyne.com/contact
Our team answers your questions about fitting and compatibility.