VELKYNE

USER GUIDE

HIDDEN UNDER-SADDLE AIRTAG MOUNT, ANTI-THEFT

A two-part ABS housing that clamps onto the saddle rails with security bolts and holds an Apple AirTag out of sight, dry, without blocking its signal. Fitting, Find My, battery, care. AirTag not included.



REF. AN2 · RAILS 7 MM, 7 × 9 AND 7 × 10 MM · ABS, SECURITY BOLTS, SCREWDRIVER SUPPLIED

01 · FITTING

CONTENTS, COMPATIBILITY, FITTING

In the box

- Upper cover and lower cover, 2 security bolts, 2 lock nuts, 4 rail adapter inserts, the special screwdriver, a manual.
- **The AirTag is not supplied.**

Fitting, step by step

1. **Check the rails and the room.** Round 7 mm rails or oval 7 × 9 and 7 × 10 mm rails, and enough space under the shell, between the rails, for the housing.
2. **Open the mount** by separating the two covers, and lay the AirTag in its recess.
3. **Pick the adapter inserts** that match the shape and section of your rails, and set them in their slots.
4. **Close it round the rails:** upper cover and lower cover either side, double clamping top and bottom.
5. **Tighten the security bolts** with the special screwdriver, lock nuts in place, until the housing no longer moves by hand. Without forcing: ABS does not like excess.
6. **Check** that the mount is stable and that the AirTag shows in the Find My app.

Specifications

Tracker	**Apple AirTag (not included)**	Rails	**7 mm, 7 × 9 mm, 7 × 10 mm**
Material	**Moulded ABS**	Fixing	**Double clamp, 2 security bolts**
Protection	**Splashes, AirTag kept dry**	Signal	**Bluetooth unobstructed**
Bikes	**Road, gravel, MTB**		

BEFORE RIDING

- The housing does not turn on the rails and touches neither the seatpost nor the clamp.
- Nothing rubs on your thighs when pedalling, no rattle.
- The AirTag shows in Find My.

THE SCREWDRIVER

Keep it at home, not on the bike: it is the one tool that reopens the mount the day the AirTag battery needs changing.

02 · DAY TO DAY

FIND MY, BATTERY, CARE, TROUBLESHOOTING

What the AirTag does, and what it does not

An AirTag is not a GPS tracker: no subscription, no real-time tracking. Its position is relayed by iPhones and Apple devices passing nearby, through Apple's Find My network, and shows in the Find My app as a last known location. In town it updates often; in open country sometimes not at all. The mount hides and holds it, it changes nothing about its range.

IT ADDS TO A LOCK, IT DOES NOT REPLACE ONE

Always lock the bike with a mechanical lock. The mount makes the tracker invisible and hard to remove with ordinary tools; it does not hold the bike.

Battery and care

- The AirTag battery lasts about a year; the app warns when it runs low. Undo the bolts with the special screwdriver, change the battery, refit.
- The housing protects from splashes and dust, not from immersion: avoid a direct jet under the saddle when washing.
- Check the tightness after the first ride, then from time to time.
- No solvent or degreaser on ABS; damp cloth.

IF SOMETHING GOES WRONG

- **The mount turns on the rails**: adapter insert wrong for the section, or not tight enough; change insert, retighten.
- **The housing will not close**: inserts misplaced, or rails outside the intended sections.
- **The AirTag no longer shows**: flat battery, or no Apple device has passed nearby since the last update.
- **A noise under the saddle**: the housing touches the clamp or post; shift it along the rails.



AirTag in the lower cover, inserts on the rails, upper cover on top, security bolts tightened with the special screwdriver.

On video

Independent tutorials on AirTags and bikes, scan to watch.

How to properly AirTag a bike
Anthony Mendez · English

5 places to hide an Apple AirTag on your bike
jaselikesbikes · English

Need help?

velkyne.com/contact
Our team answers your questions about fitting and compatibility.