QUICK GUIDE

E-BIKE HANDLEBAR COVER

Black polyester cover, 91 × 23 cm, that wraps the handlebar and the whole cockpit: display, controls, grips, brake levers. For transport on a bike rack, parking and storage, not for riding.

UNIVERSAL · POLYESTER, WATERPROOF · 91 × 23 CM, FOLDABLE



What it does

On a bike rack the cockpit takes rain and road spray at full speed; in the garage or outside, dust and showers settle on the display and into the controls. The cover shields them over 91 cm of width and 23 cm of height: the bar of a city or trekking e-bike, display and folded mirror included. It also fits a conventional bike.

Putting it on

1. **Check the dimensions:** measure the bar end to end and the height of what sticks up (display, mirror). A very wide MTB bar may not fit.
2. **Bike switched off, cockpit dry.** A display covered wet stays wet: wipe it first.
3. **Unfold the cover fully** and drape it over the bar and the accessories you want to protect, end to end.
4. **Adjust it so it sits snug** and cannot catch the wind: on a bike rack, check at every stop that it is still in place.
5. **Take it off before riding.** It hides the brakes, the controls and the display. Let it dry open if wet, then fold it into a bag.

Care

- Hand wash in lukewarm water, air dry. No tumble dryer, no radiator: that is how the polyester keeps its waterproofing.

Specifications

Compatibility	**Universal, depending on the bar**	Material	**Polyester**
Dimensions	**≈ 91 × 23 cm**	Protects from	**Water, dust, spray**
Colour	**Black**	Storage	**Foldable and compact**

IF SOMETHING GOES WRONG

- **It shifts on the bike rack**: not snug enough, or too much loose fabric; go back to step 4 and stop to refit it rather than let it flap.
- **The grips do not fit in**: bar wider than 91 cm; it will cover the display and controls, not the bar ends.
- **Damp under the cover**: bike covered wet, or cover stored damp. Dry both in the open air.

WHAT IT DOES NOT DO

- Never ride with it on. It does not protect against immersion or a pressure washer. It covers the handlebar only: motor, battery and saddle stay exposed. Do not charge the bike with the cover over the controls.

Need help?

velkyne.com/contact

Our team answers your questions about use and compatibility.

© 2026 Velkyne. All rights reserved.